

1



• Drain pan then use a wet vacuum to remove any water or loose deposits from the surface.

6



IMPORTANT

Do not mix until you are ready to pour Pancrete

• Mix (Part A] and (Part B) together by pouring back and forth twenty times.

2



Use a wire brush or wire brush drill attachment to remove deposits and rust.

Vacuum for a second time.

7



Pour Pancrete into prepared pan surface.

We recommend coating the pan with v570 prior to using Pancrete.

3



Duct tape any small pinholes on surface.

Larger size holes should be patched with galvanized steel.

8



Wait 6 hours before returning unit to service.

Do not walk on for 24 to 48 hours or until Pancrete is thoroughly hard.

4



Insert 2.5 inch PVC into drain hole and raise hole well above Pancrete level

Use an elbow piece for side drain hole

9



When Pancrete is hard enough, hacksaw excess PVC that was inserted in step 4. File down smooth if needed.

5



Check the ambient temperature and the temperature of the surface to which Pancrete is to be applied. They both must be greater than 70 degrees F.



Controlled Release
TECHNOLOGIES

PANCRETE.COM

1-800-766-9057 | CS@cleanac.com